



Golden Tiger Telecom Pvt. Ltd.

Please visit URL [**http://setup.belkin.com/guide.html**](http://setup.belkin.com/guide.html)

You need to go into view Setup guide online

In this you should choose your operating system. We are assuming win 98 here for ease of operation

When the new page loads , you should click on next next till you get an option my connection is PPPoE. When you select that , the page will reload asking you to choose your model of router.

You have to follow instructions and keep pressing next on each step till you reach the router settings section

In router settings you will get an option dynamic Ip / static Ip / PPPoE, you have to choose PPPoe

You need to follow the PPPoE instructions till you get to Username where you need to enter username allocated to you, password uses password allocated to you

And then you need to fill in service name with name Gttpl (G -capital , t-small, t-small, p-small, l-small)

Lastly you needs to enter our DNS servers viz 124.47.163.3 and 124.47.163.2 and you are up and running